

BOTTLE UNDER COUNTER FRIDGE



SINCE 1922

RAYNERS

CATERING EQUIPMENT HIRE

WWW.RAYNERS.CO.UK

020 8870 6000

Read instructions carefully before use

Following the delivery of this appliance it must be left for a minimum of 2 hours to allow the gas to settle. If the appliance has to be tilted beyond 45 degrees to make the delivery then it must be left for a minimum of 5 hours. Failure to follow these instructions may result in serious damage being caused to the compressor.

1. Make sure appliance is placed on a flat level surface.
2. Read and understand the safety advice label which is attached to the lead.
3. Plug into a protected 13 amp electricity supply.
4. Allow approximately 45 minutes for the fridge to reach temperature before filling with goods.

In the event of a breakdown or unsatisfactory working of hired equipment Rayners Catering Hirer Ltd should be notified of the fault. No attempt should be made to repair the item unless permission has been granted by Rayners Catering Hire to do so. No responsibility will be accepted by Rayners Catering Hire for any accident or damage resulting from the use of equipment hired whatever the cause.