

# ELECTRIC TOASTER



**FIG 3**   **FIG 1**   **FIG 2**



SINCE 1922

# RAYNERS

CATERING EQUIPMENT HIRE

WWW.RAYNERS.CO.UK

020 8870 6000

## Read instructions carefully before use

1. Place on a flat and level surface.
2. Read and understand the advice label which is attached to the lead.
3. Plug into a 13 amp electricity supply.
4. If you run this appliance off an extension lead make sure that it is fully unwound.
5. Using the selector button (**FIG 1**) choose required quantity of toast to be made. 2-4-6
6. Starting left to right insert required amount of bread into the slots.
7. Turn timer control knob (**FIG 2**) clockwise, for required toasting, for example 1=light 3=well done. There are multiple settings indicated on the dial.
8. Push lever (**FIG 3**) to lower the bread into the toaster the red neon will illuminate.
9. When the timer has completed its cycle the red neon will go out, and the element will stop toasting. The toast is now ready.
10. This is a manual toaster there will be no other indication that the toast is ready.
11. To take out the toast raise the lever (**FIG 3**) fully.

## SAFETY

1. Never put fingers inside the element compartments.
2. The elements are very fragile do not push any utensils into the element compartments.
3. The power cord is a tripping hazard use caution.

In the event of a breakdown or unsatisfactory working of hired equipment Rayners Catering Hirer Ltd should be notified of the fault. No attempt should be made to repair the item unless permission has been granted by Rayners Catering Hire to do so. No responsibility will be accepted by Rayners Catering Hire for any accident or damage resulting from the use of equipment hired whatever the cause.