

TWIN BOILING RING ELECTRIC 3KW



FIG 1 FIG 2



RFH

SINCE 1922

RAYNERS

CATERING EQUIPMENT HIRE

WWW.RAYNERS.CO.UK

020 8870 6000

Read instructions carefully before use

1. Place appliance on a flat level surface.
2. Read and understand the safety advice label which is attached to the lead.
3. Plug into a 13 amp electricity supply.
4. If you use an extension lead with this appliance make sure that it is fully unwound.
5. The two rings work independently of each other, turn the heat control knob **(FIG 2)** to the required heat setting: **HIGH-MEDIUM-LOW.**
6. Red neon will illuminate. **(FIG 1)**
7. Repeat for second ring.

SAFETY

1. Power cord is a tripping hazard use caution.
2. This appliance will get very hot very quickly, use away from vulnerable people.
3. Do not attempt to move until the appliance has cooled down fully and been unplugged from the mains.

In the event of a breakdown or unsatisfactory working of hired equipment Rayners Catering Hirer Ltd should be notified of the fault. No attempt should be made to repair the item unless permission has been granted by Rayners Catering Hire to do so. No responsibility will be accepted by Rayners Catering Hire for any accident or damage resulting from the use of equipment hired whatever the cause.